

Disposable COOLVEST

Made in the U.S.A

Instructions for Use:

- 1) Fill cooler with ice and 1 gallon of water
 - For use with Cooling Pad skip to #4
- 2) Put on Disposable COOLVEST®
- **3)** Adjust Velcro as necessary.
- **4)** Attach hoses to Disposable COOLVEST® or Cooling Pad. Audible click means secured hoses.
- 5) Press ON/OFF switch to ON

NOTES:

- Water hose connections are quick release dry-break connectors
- Upon initial use, allow 1-2 minutes for the Disposable COOLVEST® to fill with water
- Use hose flow controller to control temperature of Disposable COOLVEST®

Troubleshooting:

- 1) Pump Motor Not Running: Check electrical connections.
- 2) Water not flowing: Reconnect hoses at cooler and Disposable COOLVEST®

 Add water if needed

Maintenance:

COOLER:

- Add 2 ounces of Maintenance Additive (MA-16) to ice water with each use.
- Dry inside of cooler with a soft cloth after each use.

HOSES:

- Replace O-rings yearly or as needed.
- Use a soft cloth with mild soap and water to clean hoses.

© 2014 COOLSHIRT SYSTEMS, 170 Andrew Drive, Stockbridge GA 30281
Office: 800-345-3176 Fax: 678-289-4325 www.coolshirt.com