

MobileCool WP1

Made in the U.S.A

Congratulations on your purchase of the world's finest Mobile Cooling System

Included with your system:

| <u>Quantity</u> | <u>Part #</u> | <u>Description</u> |
|-----------------|---------------|--|
| _____ 1 | 2001-0006 | MobileCool WP1 |
| _____ 1 | 5004-0001 | Standard Lithium 7 Hour Rechargeable Battery |
| _____ 1 | 5004-0002 | Single Battery Charger |

Dimensions of system are (9in x 8in x 2in) and weight is 1.8 pounds

All products are guaranteed for one year from the initial date of purchase for defects in material and workmanship. If you have any questions, please call COOLSHIRT SYSTEMS Customer Service at (800)345-3176. We appreciate your interest in our personal cooling products.

Operating Instructions:

1. Belt Adjustment

- 1) This unit comes with an adjustable belt that ranges from 20 inches to 54 inches in length. Simply slide the belt through the adjusting brackets to the desired length for proper fit.
- 2) Once the belt is properly adjusted, slide belt through loops on waist pack

2. Battery Charging and Installation

- 1) Included with your system are a lithium 12v battery and charger. Charging time is 3 hours
- 2) Plug the battery into the charging cord. A red light located on the charging cord will indicate that the battery is properly connected and charging. The light will turn green when the battery is fully charged. Completely charge the battery for 4 hours prior to first use.
- 3) Re-insert the battery on either side of the pump located in the battery pouch.
- 4) Secure remaining cord into the pump pack
- 5) Close the compartment.

3. Endurance Ice Use and Installation

- 1) The system comes with two packs of Endurance Ice to be placed in a freezer until frozen all the way through for maximum cooling times.
- 2) Open the Cam-Lock bladder located in the "cooler" bag.
- 3) Place one* endurance ice pack in the Cam-Lock Bag. *Using more than one endurance ice will strain bladder causing damage to system.

Operation (Continued):

- 1) In the Water Bladder add ½ an ounce of Maintenance Additive (#5003-0001). Add 16 ounces of clean water.
- 2) Fill the remainder of the Water Bladder with cubed ice.
- 3) Seal the Water Bladder containing the endurance ice, the Maintenance Additive, and the clean water, checking to ensure a tight and complete seal has been made on the Water Bladder.

WARNING! The unit will leak if you do not ensure that the water bladder is sealed.

- 4) Fold over the top of the Water Bladder and zip the cooler bag pack closed.
- 5) Using the properly adjusted waist belt, attach the system to your waist.
- 6) Turn the belt so that the packs are located on your left side for easy connection and installation of the COOLSHIRT or Active Aqua Vest. With all connections made turn the waist belt to place the pack in a comfortable position.
- 7) Connect the battery and press the “ON”, you should feel a slight vibration and hear a low hum.
- 8) Within 30 seconds you will feel the COOLSHIRT or Active Aqua Vest begin to cool indicating proper connections and installation of the systems components.

Maintenance:

- 1) After each use of the system the unit should be drained. Open the Water Bladder and pour out contents of the system.
- 2) Connect lithium battery to the charger and re-charge the battery pack.